

## **Installation Instructions for Frameless Flat Rooflights**

Tools and accessories required to carry out the installation:

- Cordless screwdriver
  - Stanley knife
  - Glass suckers
  - Sealant Gun
  - Sealant for application
1. Check that the upstand is square and to the correct dimensions.
  2. Unpack the rooflight by removing the protective corners.
  3. Check that the upstand is between 3 and 5 degrees and is clean ready for the sealant to be applied.
  4. Apply a bead of sealant around the top edge of the upstand making sure that the bead of sealant is 10 – 12 mm high all the way round.

**PLEASE NOTE: The sealant used for sealing the Rooflight to the upstand needs to be compatible with the roofing substrate**

5. Lower the Rooflight over the upstand into position and press down firmly making sure there is a good adhesion all the way round.
6. Once you are happy with its position bend the internal straps down and fasten into position with screws, being careful not to pierce the external roof membrane.
7. Remove the glass film and rooflight protection.

**PLEASE NOTE: Roof protection film and packaging must be removed on the day of installation as it is NOT designed to be left on the product for a long period of time.**

8. Clean the glass and frame of any packing residue with glass cleaner or warm soapy water.

**If you have any problems with the installation of this product, please do not hesitate to contact us and we will help guide you through it.**

### **Glass Roofs UK**

trading as Total Installations Limited  
102-120 North Lane – Aldershot – Hampshire – GU12 4QN  
Tel: 01252 336614 – Fax: 01252 341035  
Email: sales@totalinstallations.com  
Website: www.glassroofsuk.com